

09730658-120600




Fig 1

HARDWARE DIAGRAM





Fig. 2

FUNCTIONAL DIAGRAM

IR Signal



A=the number of the remote Control Device

X1= 10%, X2=20%, ..., X10=100%




Fig. 3